

Bishop Cochran

Spring Kit
For plunge router bases
(except laminate trimmer models)

Converts the Router Base to spring plunge

INSTALLATION

- Remove the vertical height adjustment knob from the router base
- Lift the tool carriage off the posts, **being careful to catch the tiny brass pad** which is behind the vertical height lock knob
- Slide the springs over the vertical posts
- Re-install the carriage over the posts
- Remove the vertical lock knob
- Insert the brass pad in the hole (the brass pad keeps the post from being marred).
- Re-install the vertical height lock knob
- Thread the T-shaped knob over the vertical height adjustment screw
- Thread the 1" lock knob on top of the T-shaped knob

INSTRUCTIONS FOR USE

- In using the spring-loaded function, it is important that the vertical lock knob be screwed down firmly over the T-knob. This prevents the plunge depth from changing as a result of mechanical vibration.

Bishop Cochran/Rob Shoemaker

Phone: (503) 777-0955

Email: bishopcochrantools@gmail.com

<http://www.bishopcochran.com>

We welcome your questions, suggestions and comments.